

AIRBENCH MODULAR RACKING & ASSEMBLY SYSTEM



TECHNICAL SPECIFICATION

COMPATIBILITY	All AirBench Models
FINISH (STD)	Textured grey powder coat
AIRLINE	Requires external compressed air supply. Series 19 push fit as standard. Other connectors as options.
240 V SOCKETS	Require external 240 V power supply OR may be connected to AirBench supply. When connected to AirBench supply, total load including AirBench must be less than 13A.
110 V SOCKETS	Require external 110 V power supply OR may be connected to transformer housed in AirBench body. When connected to transformer, total load including AirBench and transformer supply must be less than 13A.

FEATURES

- Assembly bench system
- Modular and easy to update
- Enables addition of further accessories

OPTIONS

- Storage
- Power and air connections
- Lighting



STANDARD ENCLOSURE

500 mm high enclosure with plain rear panel.

Enables addition of racking, lighting, and alternative service panels.

AES OFFER INSTALLATION AND SERVICE SUPPORT FOR ALL EQUIPMENT

AIRBENCH MODULAR RACKING & ASSEMBLY SYSTEM



SUPPORT RAILS

Bolted to rear enclosure panel to support lighting and shelving.

Adjustable - can be mounted at any height.
Requires enclosure.



SHELF

300 mm deep shelf for parts storage.

Requires enclosure and support rails.



LIGHT

LED panel lighting on frame to illuminate workspace.

Requires enclosure and support rails.



PARTS BIN RAILS

Alternative rear enclosure panel with rails for parts bins.

Requires enclosure.

AES OFFER INSTALLATION AND SERVICE SUPPORT FOR ALL EQUIPMENT

AIRBENCH MODULAR RACKING & ASSEMBLY SYSTEM



DOUBLE SOCKET SERVICE PANEL

Replacement service panel with double socket.

Requires standard enclosure.

Power from external supply or AirBench outlet.



AIRLINE SERVICE PANEL

Replacement service panel with 4 x series 19 pushfit airline connectors.

Requires external air supply and standard enclosure.




AIRLINE/SOCKET SERVICE PANEL

Replacement service panel with double socket and airline connectors.

Requires external air supply and standard enclosure.

Power from external supply or AirBench outlet.



110 V SERVICE PANEL

Replacement service panel with twin 110 V sockets.

Requires external 110 V supply and standard enclosure.

Power from external supply or optional transformer.

AES OFFER INSTALLATION AND SERVICE SUPPORT FOR ALL EQUIPMENT

AIRBENCH MODULAR RACKING & ASSEMBLY SYSTEM



DOUBLE SOCKET SERVICE CHANNEL

Service channel with double socket.

Requires standard enclosure.

Power from external supply or AirBench outlet.



AIRLINE SERVICE CHANNEL

Service channel with 4 x19 pushfit airline connectors.

Requires external air supply and standard enclosure.




AIRLINE/SOCKET SERVICE PANEL

Service channel with double socket and airline connectors.

Requires external air supply and standard enclosure.

Power from external supply or AirBench outlet.



110 V SERVICE CHANNEL

Service channel with twin 110 V sockets.

Requires external 110 V supply and standard enclosure.

Power from external supply or optional transformer.

AES OFFER INSTALLATION AND SERVICE SUPPORT FOR ALL EQUIPMENT